

astutO QUICK GUIDE



Always operate upside-down for opening and folding
Press buttons to release the feet



TO OPEN



Push buttons

Keep buttons pushed while opening feet

Move locking sliders

TO FOLD

Rear slot for watching videos, browsing and typing with the Teclado keyboard

Turn both wheels to adjust the rear slots width

Front slot for typing on the tablet's software keyboard

Instant attachment system for the Teclado keyboard

Push both buttons to release feet

Move both sliders to lock the plate



WARNING

Pinch Points
Be carefull when opening / closing the stand.